

**IMPORTANT:** Please read carefully the following instructions before beginning.

**OLD WORK**  
 Unscrew the four screws at the bottom of the box to remove leveling feet.

**1**

Determine box location and position in accordance to floor plans.  
 Adjust the leveling screws until the desired level is met.

**2**

Attach conduits to the selected knockouts.  
 Install temporary cover to prevent debris from entering the box during concrete pour. Duct tape any cracks or seams where concrete may enter.

**3**

Fix and secure box to the floor using concrete mix.  
 Add concrete mixture below and around box (if necessary) to level the box in accordance to the final floor level desired.

**4**

Hand toweling near box edges is suggested once concrete has been poured.

**5**

Once concrete has cured, remove temporary cover. Locate and pull wires.

**Warning:**

To be installed and/or used in accordance with appropriate electrical codes and regulations.

**Warning:**

To avoid fire, electrical shock and/or electrocution turn power OFF at the circuit breaker before wiring.

**6**

Install the desired floor covering material (terrazzo, tile, limestone, carpet, etc) on the floor.


**7**

Wire devices in accordance with the NEC.  
 Attach faceplates to mounting panels.


**Caution:**

Wire devices in accordance with the NEC.  
 If you are not sure about existing conductor wires, color coding, polarity and circuit feed contact a licensed electrician.






**8**  
 Before installing the cover, apply a generous amount of silicone caulk around the opening of the floor box (where the flange sits) . Verify that all the perimeter has been properly sealed.




**9**  
 Secure the cover to the box using the four supplied screws.



**10**  
 Installation Complete.


**Leveling the Box**

**CORRECT**




When a floor covering thickness is known in advance (tile, wood, carpet), estimating level to obtain a floor covering flushed with floor box is suggested (as shown on the figure above) However it is not completely necessary


**Non-Beveled Cover Installation**




- 1) Depending on the thickness of the floor covering material, level the box as necessary to obtain a flush finish between the cover and the final floor level as shown on the illustration.
- 2) Before installing the cover, apply a generous amount of silicone caulk around the opening of the floor box. Verify that all the perimeter has been properly sealed.
- 3) Secure the cover to the box using the four supplied screws.



When concrete is over poured, the cover can still be applied.



When concrete is flushed with box, the cover can be applied.



**Avoid this situation**

